



MANAGE MY SOFTENER

SALT ALARM
PLUS

SALT ALARM PLUS

Please press any button on the valve control to stop the alarm and proceed with the steps as shown in the app:

1

Please refill the container with salt.

2

Reset the salt level. For your type of unit, step 2 requires no action on your part. Your softener is equipped with a fully automatic salt alarm and you don't have to do anything to reset it. The control valve will perform an automatic conductivity check during every regeneration.

If a salt alarm is triggered while your unit still has plenty of salt, you may want to contact your supplier.

SALT CONCENTRATION HISTORY

You can also check the salt concentration history on your device.

1

To do so, you will have to press the combination of **+** and **–** and hold for three seconds. You will see the following screen:

DAYS SINCE REGEN

2

2

Press **next** until you see the following screen:

REGEN

% BRINE

A

\\///
15
///\\

90

3

Press **+** or **–** to go through the last 50 regenerations. The number on the left signals how many regenerations ago the reading was taken. "A" indicates it was an Alternate Regeneration. The number on the right signals the brine quality. On a unit that is functioning properly, you will expect to see 100% when the brine quality is good and you will see the number gradually drop as the unit is running out of salt. When the brine quality is too low (below 50%), an alarm will be triggered.