



MANAGE MY SOFTENER

FIREWALL SETTINGS



Manage My Softener.
The smartest way to
carefree water.



MANAGE MY SOFTENER

FIREWALL SETTINGS



SETTINGS
CLACK

TCP Port 1883

needs to be opened

TCP port 8883

needs to be opened

**HTTP & HTTPS access needs
to be granted to the website
managemysoftener.com.**

